

PH: (269) 382-2050

www.kalamazooind.com

S4S AND S4 BELT SANDER MANUAL









PH: (269) 382-2050

www.kalamazooind.com

INSPECTION

If these goods are damaged in transit, the **DELIVERING TRANSPORTATION COMPANY** is required by law to make notation of damages on the freight bill. If in your opinion, there may be concealed damage, they are required to make an inspection after goods are unpacked. Transportation rates are made in proportion to damage. Therefore, the carrier and **NOT** the shipper should be charged with any loss or damage. Any claim should be filled with the delivering **TRANSPORTATION COMPANY**. **PLEASE DO NOT RETURN GOODS TO US WITHOUT OUR RGA NUMBER AND SHIPPING INSTRUCTIONS**.

NOTE: SEE NEXT PAGE FOR RETURN POLICY AND WARRANTY.

READ OPERATING INSTRUCTIONS AND PRECAUTIONS BEFORE USING EQUIPMENT

OPERATING INSTRUCTIONS

- 1. Disconnect power before making any adjustments.
- 2. Abrasive belt rotation is counter-clockwise. If the abrasive belt is lap spliced be sure of correct rotation. Butt spliced belts are bi-directional
- 3. Belt tension is pre-set with internal spring. No belt tension adjustment is needed.
- 4. Belt changing: Disconnect power, squeeze belt manually, align flip cam to hold tension spring closed (A), remove belt and install new belt, move flip cam back to position (B) to tension.
- 5. Belt tracking: Tracking screw twits yoke to center belt. With power OFF spin belt manually to verify belt tracking, adjust tracking screw to center belt, tighten jam nut to lock tracking screw. Jog belt with power ON to check belt centering or "tracking".
- B
- 6. Always keep the work table within 1/8" of sanding belt. This will avoid pinching material between sanding belt and platen.
- 7. Examine the abrasive belt carefully before use. Never use an abrasive belt with a nicked or cut edge, crease or handing damage.
- 8. If you are using a dust collector, bags should be emptied frequently during use to maintain efficiency and prevent buildup of combustible materials.



PH: (269) 382-2050 www.kalamazooind.com

WARRANTY

All products are guaranteed for a period of one year from receipt of order to the original purchaser, against defects in material workmanship under normal use. Electric motors are warranted by the motor manufacturer for a period of one year and will be repaired by the nearest motor repair station. If non-repairable, they will be replaced by Kalamazoo Industries. Please call for instructions (269) 382-2050.

RETURN POLICY

Authorization must be obtained before returning merchandise. Please call our customer service department for a return authorization number (269) 382-2050. Please include with your return a copy of your invoice of packing slip. All material must be new and unused in the original packaging. Material must be sent back prepaid (unless otherwise indicated) by Kalamazoo Industries. Credit upon inspection at Kalamazoo Industries. All returns will be subject to a 10% restock charge. Used merchandise is non-returnable. No returns will be accepted after one year of invoice date.

BELT SANDER SAFETY

- READ THE OPERATING INSTRUCTIONS BEFORE RUNNING MACHINE.
- ALWAYS WEAR SAFETY GLASSES OR A FULL FACE SHIELD FOR PROTECTION.
- KEEP HANDS CLEAR OF THE SANDING AREA.
- NEAR WEAR GLOVES OR LOOSE FITTING CLOTHES WHEN OPERATING THIS MACHINE.
- ALWAYS KEEP HAIR TIED BACK OR COVERED.
- LET MACHINE ROTATION COME TO A FULL STOP BEFORE CHANGING BELT.
- KEEP SAFETY GUARDS IN PLACE. DO NOT ALTER GUARD OR MACHINE IN ANYWAY. ANY ALTERATIONS TO GUARDS OR MACHINE COULD CAUSE SERIOUS INJURY.
- ALL BELT SANDERS SHOULD BE OPERATED IN A WELL-VENTILATED AREA. THE
 DUST CREATED WHEN SOME MATERIALS ARE SANDED CAN BE HARMFUL. DUST
 MASKS ARE RECOMMEND AS A PRACTICAL MEAN OF MINIMIZING DUST
 INHALATION. FUMES FROM OTHER OTHER SOURCES CAN ALSO CAUSES FIRES
 WHEN INTACT WITH SANDING SPARK.
- SPARKS CREATED BY SANDING SHOULD BE DIRECTED DOWNWARD AND AWAY FROM THE FACE AND BODY. DON NOT GRIND NEAR FLAMMABLE MATERIAL.
- ELECTRIC SANDING MACHINES ARE NOT INTENDED FOR USE IN OR NEAR WATER. THIS INCLUDES AN OPERATOR STANDING ON A WET FLOOR OR WORKING AROUND CONTAINERS OF WATER OR OTHER CONDUCTIVE LIQUIDS.



