Parts List


Part No.		City.		Description	Qty.		Description	City.
1	Base	1	36	Spring Pin		71	Ter Screw	4
2	Column	11	37	Worm Gear	1	72	Fixed Washer	8
3	Cover/Support	1	38	Washer	1	73	Motor Base	2
4	Screw	4	39	Fixed Washer	1	74	Washer	4
5	Spring Washer	4	40	Sheave Stand		75	Fixed Nut	4
6	Set Washer	4	41	Lock Handle	1	76	Fixed Screw	4
7	Motor Mouré	11	42	Knob	Ħ	77	Steel Wesher	8
8	Upper Spring Pin	11	43	Reck	1	78	Motor	11
9	Stud Bolt	11	44	Rack Set Screw	2	79	Nut	4
10	Fixed Nut	11	45	Solid Segment	1	80	Cord	11
11	Sel Spring Washer	11	46	Table	1	81	Equal Key	4
12	Fixed Washer	1	47	Screw	T	82	Screw	3
13	Spring Stud Bolt	11	48	Fixed Pin	1	83	Fixed Washer	3
14	Stud Wesher	11	49	Table Adi.	1	84	Hub	11
15	Bracket	11	50	Table Screw	11	85	Dec	11
16	Spring	2	51	Table Washer	1	86	Clamp Block	1
17	Keeper	12	52	Pilot	11	87	Clamp Screw	1
18	Sheave	12	53	Plot Screw	4	68	Sanding Cloth	1
19	Fixed Screw	1	54	Spring Pin	1	89	Dec Guert	1
20	Fixed Washer	12	55	Piot	1	90	Left Arm Guard	11
21	Fixed Nut	11	56	Gear Segment	1	91	Right Arm Guard	1
22	Pin	7	157	Scale Set Knob	dominana a	192	Guard Screw	4
23	Screw	1	158	Scale Plate		193	Guard Washer	4
24	Fixed Nut	11	159	Gear Segment	11	194	Guard Brackel	2
25	Wire Rope	TT	160	Worm Til	11	95	E CON	12
26	Screw Bracket	1	181	Spring Pin		86	l Washer	2
27	Hardie	1	82	Shaft	11	97	Sei Screw	12
28	Handle Wheel	11	63	Screw	11	98	Set Washer	2
29	Set Screw	11	164	Politier	11	99	l Set Nut	12
30	Shaft Base	1	165	Knob	11	100	Adj. Screw	12
31	Set Screw	4	66	Scale Set	11	101	Switch Plate	11
32	Steel Washer	14	67.	Protractor	1	102	Screw	12
33	I Shall	7	168	[Nail	13	103	Switch Control	11
34	Wester	12	169	Set Screw	17	104	Screw	14
35	Soring Pin	17	70	Set Nut	11	1105	Steel Washer	14

PLEASE READ THE FOLLOWING CAREFULLY

THE MANUFACTURER AND/OR DISTRIBUTOR HAS PROVIDED THE PARTS DIAGRAM IN THIS MANUAL AS A REFERENCE TOOL ONLY. NEITHER THE MANUFACTURER NOR DISTRIBUTOR MAKES ANY REPRESENTATION OR WARRANTY OF ANY KIND TO THE BUYER THAT HE OR SHE IS OUALIFIED TO MAKE ANY REPAIRS TO THE PRODUCT OR THAT HE OR SHE IS QUALIFIED TO REPLACE ANY PARTS OF THE PRODUCT. IN FACT, THE MANUFACTURER AND/OR DISTRIBUTOR EXPRESSLY STATES THAT ALL REPAIRS AND PARTS REPLACEMENTS SHOULD BE UNDERTAKEN BY CERTIFIED AND LICENSED TECHNICIANS AND NOT BY THE BUYER. THE BUYER ASSUMES ALL RISK AND LIABILITY ARISING OUT OF HIS OR HER REPAIRS TO THE ORIGINAL PRODUCT OR REPLACEMENT PARTS THERETO, OR ARISING OUT OF HIS OR HER INSTALLATION OF REPLACEMENT PARTS THERETO.

NOTE: Some parts are listed and shown for Illustration purposes only and are not available individually as replacement parts.

Assembly Drawing



Page 9